

A modern office chair with a black mesh backrest and a black seat, mounted on a white five-spoke base with casters. It is positioned in front of a light-colored wooden desk. The background features a window with vertical blinds and a glass partition.

## AG Chair

Functionality, design, and quality are the 3 main objectives we seek to achieve when designing and engineering the AGchair exudes a light and calming appearance thanks to our thinnest ever back frame, with just a 3mm edge.



Design  
Manufacture  
Create



A new and more transparent Stripes mesh further enhances its visual lightness. AG Chair is designed and certified to BIFMA X5.1 and EN-1335 standards for safety and durability, giving you a peace of mind.

### Specifications

- Synchro mechanism
- Seat slide
- Adjustable Lumbar
- With or without arms
- Black or White frame
- Grey or Black mesh
- Arms Black or Grey

### Certifications

- AFRDI Level 6

### Warranty


- 7 year warranty

### Dimensions

Description	Width (mm)	Depth (mm)	Height (mm)
Seat	450	395-475	420-520
Overall	665	475	945-1045

## AG OPERATING INSTRUCTIONS

- A Seat Height Adjustable**  
Flip up lever on right-side to raise or lower seat. Adjust such that your feet are adequately supported on floor.
- B Multi-Position Tilt Lock**  
Recline to desired position, and flip down lever to lock. Flip up lever to release tilt-lock.
- C Lumbar Height Adjustment**  
Slide the lumbar support up or down for desired lumbar position.
- D Armrest Height**  
Press the button and raise or lower the armrest. Adjust height to adequately support elbows to take strain off shoulders.
- E Armpad Angle**  
Grasp armpads and rotate them inwards or outwards to adjust elbow support to suite specific tasks. An inward position works during keyboard use, while an outward position is recommended during mousing.
- F Armrest Depth**  
Grasp armpads and push them forwards and backwards to suite your arm support.
- G Seat Depth Adjustment**  
Pull the lever under the right-side of the seat to adjust fore and aft position.
- H Headrest Height** (Only applicable for 1199 model)  
Adjust height by holding both sides of headrest and pull up or down to your desired height.



### Get In Touch

#### Sydney Office:

6-10 Phillips Road,  
Kogarah NSW 2217

#### Melbourne Office:

101 Moray Street,  
South Melbourne VIC 3205

Call 1300 362 628

Website : [www.mn8design.com](http://www.mn8design.com)

Email : [sales@mn8design.com](mailto:sales@mn8design.com)